


Advanced Buttons

Display



- The green LED shows the availability of new messages.
 - With the navigator you can browse multiple pages of the display and select a line (by default the bottom line is activated).
- Soft keys for accessing the functions offered on the display. S

Information key



For displaying information and to altering your programming.

Microphone key



So your interlocutor does not hear you.

Disconnect key



For ending a call or a programming.

Hands-free mode / volume control



Bottom: For calling a participant or for answering a call without lifting the handset.

Left: For decreasing the volume of the speakers or the handset.

Right: For increasing the volume of the speakers or the handset.

Soft key




Label of the key with alterable text

Message key

 Nachricht Access to the various message services.


Repeat dialing key

 Repeat dialing of the last called number (internal/external).

ISDN key

 ISDN Access to the ISDN services (call list and call number suppression).

Note key

 Note Repeats a previously saved external number. This number will be deleted once you press the key again.