



Advanced Komfortleistungsmerkmale


Sending text messages

To send a text message, first press the key , followed by the keys  and . Enter the number of the recipient and confirm with the key .

Now you can select the following messages:

 Defined, fixed messages




 Supplementary messages

 Messages you drew up yourself


Now confirm your entry with the keys  and . Your message was sent to the participant.

Checking text messages


The display beside the key  and the LED of your phone are flashing.


After pressing the keys ,  and , the name of the sender as well as the date and time of the message transmission will be displayed.


You now have the following options:

 Storage of received messages

 Reading the message

 Back to previous menu

 Display the following message

 The sender of the message was called back

Antwort A reply will be sent to the sender of the message

The LED only goes out when you have read and deleted the message.

Vacation message

You can leave a message on your device that will be transmitted to the display of the caller's phone.

You first press the key **Nachricht**, followed by **Texte** and **Texte**

Now you can choose from the different vacation messages:

fest Defined, fixed messages

Progr. Supplementary messages

Now confirm your entry with the keys **Bestät** and . The selected vacation message will be displayed.

To cancel the vacation message, proceed as follows:

You press the key **Nachricht** again, followed by **Texte**. Now you press the key **TextAus** and confirm with the key **AUS**.